

Installation instructions for 41645

- 1) Remove t-top to access spring hole plug (A1795). Carefully remove plug using a small flat blade screwdriver or pick.
- 2) Pry retainer (A1799A) off of existing pivot end to allow removal of spring (A1799B).
- 3) The elbow (A7198) should now slide out. If elbow is rusted or broken, use a punch to remove.

Installation of new hardware

- 1) Extend rod from telescoping sunvisor outward and install bushings (27586) around rod. These bushings will provide tension to hold sunvisor in position.
- 2) Remove the wire clip from the elbow (A1798). Reinstall sunvisor rod with new bushings (27586) into the new elbow end until slots align, allowing reinstallation of clip.
- 3) Reinstall sunvisor with new hardware back into the roof mount reverse as removal.

